

- 1. INSTALL SOCK BARRIER PER DETAIL 2 SHEET CS103.
- 2. EXISTING DRAINAGE OUTLET. DO NOT DISTURB.
- 3. EXISTING DRAINAGE INLET. DO NOT DISTURB.
- 4. EXISTING UNDERGROUND STORM DRAINAGE PIPE.
- 5. STOCKPILE TO BE SHAPED TO DRAIN SURFACE WATER. COVER TO PREVENT WINDBLOWN DUST IF REQUIRED.
- 6. 12' SOCK BARRIER OPENING (VEHICLE ACCESS).

SOCK BARRIER (WITH NON ORGANIC MATERIAL)

- 1. REFER TO SHEET CS101 FOR SWPPP NOTES.
- 2. LOCATE STOCKPILES A MINIMUM OF 15.24 METERS (50 FEET) OR AS FAR AS PRACTICABLE FROM CONCENTRATED RUNOFF, STORM DRAIN INLETS, OR OUTSIDE OF ANY NATURAL BUFFERS, IF ANY.
- EXCAVATED MATERIAL/STOCKPILES WILL BE PROTECTED WHEN (A) MATERIAL WILL NOT BE ADDED OR SUBTRACTED TO A STOCKPILE FOR A PERIOD GREATER THAN TWENTY-FOUR (24) HOURS, AND (B) WHEN A SIGNIFICANT RAIN EVENT OCCURS. PROTECTION MEASURES WILL INCLUDE PLACING WORK AREA ISOLATION DEVICES, SUCH AS GRAVEL BAG, FIBER ROLL/SOCK, AND/OR SILT FENCE AROUND THE STOCKPILE. SEE SWPPP PLANS FOR DETAILS.

ATOR **TECHNOLOGY UBMILLIME** COMMIS



Revisions	
Description	Date
DOH COMMENTS/ VE ITEMS	10/10/20
<u> </u>	
<u> </u>	
<u> 4</u>	
<u> </u>	
<u>^</u>	
Drawn:	Т

AUXILLARY STOCKPILING PLAN

Sheet Number

CS102

M3PN 160109